

ProLAST® Rebuild Kit for COBALT® Manual Flush Valves Installation Instructions

Part No. 101427 : 3000/3200 Series



KIT INCLUDES

- ProLAST® T-Seal
- Trip Mechanism
- Square-Profile O-Ring



TOOLS NEEDED

- Flat Head Screwdriver
- Smooth Jaw Wrench

EXISTING COMPONENT REMOVAL

Step 1

Remove control stop cover, if necessary. Turn adjustment screw/wheel **CLOCKWISE** to close control stop.



Step 2

Activate flush valve to relieve water pressure.



Step 3

Use a smooth jaw wrench to remove flush valve cap. Remove existing ProLAST® T-Seal, trip mechanism, and square-profile O-ring.



ProLAST® T-SEAL AND FLUSH VALVE CAP INSTALLATION

Step 1

Install new ProLAST® T-Seal, I-CON trip mechanism, and square-profile O-ring.



Step 2

Install flush valve cap onto flush valve body. Tighten by hand.



ADJUSTING CONTROL STOP

Step 1

Turn adjustment screw/wheel **COUNTERCLOCKWISE** 1/2 turn from closed position. Activate flush valve.



Step 2

To adjust flush valve, turn adjustment screw/wheel in small increments. Activate flush valve after each adjustment. The proper flow rate should completely cleanse fixture without splashing water outside of fixture.

Step 3

Reinstall control stop cap, if necessary.



INSTALLATION COMPLETE

Scan this QR code to view
Troubleshooting & Exploded
View documents on our website.

